

# ADJUSTABLE PERFORMANCE FEATURES

## Using the Synapse

Depress the \*Reset, then close the jaw around the D-Loop. Pull with slight tension against the D-Loop to ensure the jaw is locked prior to use.

## Independent Tension and Travel Adjustments

Tension: Rotate clockwise to increase, counterclockwise to decrease.

Travel: Rotate clockwise to decrease, counterclockwise to increase.

-It is possible to set the tension too light. Adjust in small increments

## Interchangeable 3rd/4th finger (figure 1)

Easily converts from a 3-finger release to a 4-finger release


## Sweeping 4th finger (figure 2)

Conforms to the archer's style and comfort by offering the ability to adjust the sweep angle of the 4th finger attachment up to 45 degrees

## Infinite position thumb post

Allows the archer to customize the thumb post to optimal position

### Figure 1. Interchangeable 3rd/4th finger



1. Using a 1/16" hex key, loosen the set screw and remove the pin as shown on left. Once the pin is removed, remove the 3-finger attachment.
2. Insert the 4th finger attachment, and replace the pin as shown. Tighten down each set screw.  
\* 4th finger attachment has two set screws

### Figure 2. Sweeping 4th finger

1. Using a 1/16" hex key, loosen/tighten the two set screws to set the desired angle of the 4th finger attachment.
2. When the desired angle is reached, make sure each set screw is tight.

